

**CLEANING OF SELECTOR AND RELAY-SET COVERS
AND INSPECTION OF FELT DUST EXCLUDERS**

[Maintenance Routine Instruction (M.R.I.) No. R131]

★[NOTE:—As this Instruction has been completely revised, individual paragraphs have not been “starred”]

1. Cleaning of Covers.—The covers should be removed and cleaned inside, and outside, as follows:—

(a) If the covers are very dirty, loose dirt should be removed from the covers with a dry duster.

(b) Apply a small amount of “Paste, Polishing, No. 4” to the surfaces to be cleaned, using a damp cloth. Rub off immediately with a clean damp cloth. Polish with a dry cloth. Subsequent wax polishing is unnecessary. The cloth used for applying the paste should be changed or washed out when dirty.

2. Check of Felt Dust Excluders.—Felt dust excluders should be inspected to verify that they are firmly affixed. “Bostik 299” should be used to re-fix any which have become displaced. Worn or damaged felts should be renewed.

To replace worn or damaged felts on selector and relay-set covers, a small quantity of suitable felt ($\frac{1}{8}$ in. thick) should be purchased locally and cut to the required size. New felts for the base-plates of pre-2000-type selectors may be obtained from the Piece Part Depots.

Reference:—None
(Tp 2/4)

E N D

[Crown Copyright Reserved]

Page 1
Issue 4, 27.3.57